

- ✓ Tray with wheels and chain for gas bottle
- ✓ Double wire feed
- ✓ Infinitely adjustable
- ✓ ABS shock resistant housing
- ✓ 5 years warranty



SOLDERATECH
powered by **HG**

SOLDERATECH
powered by **HG**

MIG MAG welding machine 200A

product code: ML200YHG

This Solderatech powered by HG MIG / MAG welding machine is standard equipped with a carrying platform to attach the gas bottle. This machine makes it possible to carry out various welding processes with ease, including MIG welding and also electrode welding.

The modern IGBT inverter technology ensures that the ML200YHG delivers sustainable performance with more power and a very high duty cycle. The ML200YHG is also equipped with thermal safety as standard, which in combination with a built-in fan prevents overheating and ensures that high-quality welding performance is guaranteed for a long time.

The hot-start/anti-stick function increases the welding current quickly, so that the electrode does not stick to the workpiece during ARC welding.

Ideal for welding stainless steel, carbon steel, low alloy steel and aluminium (without pulse).

Every ML200YHG comes standard with:

- Solderatech MLT24M3 MIG torch with Euro connector and 3m cable
- Ground clamp with 3m 25mm² cable
- Standard 13mm Dinse cable coupling
- Gas pipe of 4m with quick coupling
- Heat resistant cover
- 3m 3x4mm² cable without plug
- 1x wire drive roll: 0.8 + 1.0

Specifications

voltage	230 V
frequency	50/60 Hz
input current	39,5 A
input power	10kVA
start-up voltage	55 V
duty cycle	80% - 200 A
welding current range	MIG 30-200 / MMA 30-200
weldable welding wire	0.8 / 1.0 / 1.2
protection class	IP21S
dimensions	990 x 495 x 720 mm
weight	52 kg

SOLDATECH HG

powered by

Legend ML200YHG



IGBT
The latest IGBT inverter technology guarantees the best welding performance.



Slow Wire Feed
At start-up, the wire starts slow, then accelerates to the selected settings once ignition is successful.



DC
Constant DC power output.



Digital
Digital display.



Thermal protection
Prevents overheating of the welding machine.



Burn Back Time
Once welding stops, the welding current and gas flow continue so that the welding wire does not jam and get stuck in the weld.



Anti-stick
The anti-stick function ensures that electrodes do not stick and weld easily.



2T/4T
2T: Press 1x for on. Release for off.
4T: Press and release 1x for on. Press again and release for off.



Hot start
The hot start ensures a high start-up voltage so that all types of welding electrodes ignite easily.



A stepless
Infinitely adjustable Ampere to an accuracy of 1 ampere.



V stepless
Infinitely adjustable voltage.



1Phase
1 phase 230V input.



ARC FORCE
With the ARC FORCE, welding depths can be easily set during electrode welding.



Arc Welding
Welding machine can also ARC weld (electrode welding).



Flux
Reverse polarity is possible so that powder-filled wire can be welded gas-shieldedly.



Inductance
Adjustable induction allows the width and depth of the weld pool to be adjusted in MIG welding.



Double Wire Feed
Double roll wire feed.